



## PRONG SNAP BUTTON WITH CRYSTAL TOP / TAŞLI KLİKİT



**1105A**

D 7.5 / h 4.78

**CRYSTAL TOP**



**1205A**

D 8.5 / h 5.21



**1305A**

D 10 / h 6.30



**1101B**

D 7.5

**DIŞI / SOCKET**



**1201B**

D 8.5



**1301B**

D 9.5



**1101C**

D 7.5

**ERKEK / STUD**



**1201C**

D 8.5



**1301C**

D 9.5



**1101A**

D 6.8 / h 2.60

**PRONG - RINGS / TIRNAK**



**1201A**

D 7.8 / h 2.82



**1301A**

D 9.5 / h 3.40



## PRONG SNAP BUTTON WITH CRYSTAL TOP / TAŞLI KLİKİT



**1410A**

D 11.5 / h 7.14

**CRYSTAL TOP**



**1401B**

D 10.5

**DİŞİ / SOCKET**



**1401C**

D 10.5

**ERKEK / STUD**



**1401A**

D 10.5 / h 3.90

**PRONG - RINGS / TIRNAK**



**1608A**

D 21 / h 10.86

**CRYSTAL TOP**



**1601B**

D 15

**DİŞİ / SOCKET**



**1601C**

D 15

**ERKEK / STUD**



**1601A**

D 15 / h 5.30

**PRONG - RINGS / TIRNAK**